

Self-Recovery Winch

Model: Walrus 18.0

PN: 281800 12V 281810 24V 281820 12V 281808 24V

Introduction

► Feature

Line pull:	8,165 kg / 18,800 lb wire rope first layer
Wire rope:	11.1 mm × 27 m (7/16"×89′) 6 × 29 - IWRC
Brake:	Patented cone brake holds full load
Clutch:	Turn the T-handle for rapid wire rope payout
Control:	Handheld pendant switch powers the winch

Unpacking

• Winch assembly	1 po	С
Potted control box	1 po	С
Remote control	1 po	С
Wire rope with hook	1 po	С
• Roller fairlead	1 po	С
Cable Tensioner	1 po	С
• 1.8 m (6′) 2 gauge battery lead	1 po	С


Read this manual carefully

You should carefully read and understand this manual before operating it. Careless winch operation may result in personal injury hazards or property damage.

Installation

Before using the winch, make sure all electrical components have no corrosion or damaged; the environment should be clear and dry.


- ▶ Winch and roller fairlead mountings
 - It is very important that the winch will be mounted on a flat and hard surface of mounting channel in order to make sure the motor, drum and gearbox housing are aligned correctly.



- · Roller fairlead does not mount to the winch directly.
- The wire rope shall be wound in an under-wound orientation only.
- Eight (8) M12 x 1.75 pitch SUS high tensile steel bolts must be used in order to sustain the loads imposed on the winch mounting.
- Two (2) M12 x 1.75 pitch SUS high tensile steel bolts must be used for fastening the roller fairlead into the mounting channel.

► Wiring Diagram


- Connect thermal sensor harness plug, control ground to the motor.
- Attach the ground lead firmly to the negative (–) battery terminal and power lead to the positive (+) battery terminal. The voltage drop for the winch motor must not exceed 10% of the nominal voltage of 12/24V DC.



▶ Nut fastening for motor & contactor

1. Holding the lower nut on the stub and fastening the upper nut clockwise.

2. The torque setting for nut is 14 N-m/124 lb-in.



Warning

- The winch is not intended to be used in any manner for the movement or lifting of personnel.
- \cdot The rated line pull shown is based on the first layer of rope on the drum.
- \cdot The rope winding on the drum shall remain 5 wraps from the drum.

Parts List

Item No.	Description	Part No.	Qty
1	Waterproof motor w/control box 12V	883072	1
1	Waterproof motor w/control box 24V	883073	1
2	Tie bar kit	883000	3
3	Motor coupling	882201	1
4	Drum bushing	880048	1
5	Drum kit	883077	1
6	Drum bushing	882204	1
7	Gearbox support rack	883080	1
8	Grounding lead	880009	1
9	Wire rope	883081	1
10	Clevis hook	883009	1
11	1 st shaft	882206	1
12	3 rd ring gear kit	882208	1
13	3 rd stage carrier	882209	1
14	2 nd stage carrier	882211	1
15	1 st stage carrier	882212	1
16	1 st pinion	882213	1
17	Clutch kit	883125	1
18	Gear box kit	883086	1
19	Cone brake disc kit	882216	1
20	Brake clutch base	882217	1
21	Brake cover kit	883087	1
22	Roller fairlead	882990	1
23	Cable tensioner	883090	1
24	Mounting hardware	883092	1
25	Remote control	881671	1
26	Handsaver strap	880026	1

Winch Assembly

