

Model: SOLO 12.5rs TE

PN: 291500 12V DC 291508 12V DC

Introduction

► Feature

Line pull:	5,670 kg / 12,500 lb synthetic rope first layer
Synthetic rope:	11 mm × 21 m (7/16"×69′)
Brake:	Patented cone brake holds full load
Clutch:	Turn the T-handle for rapid rope payout
Control:	Both handheld pendant switch and built-in digital
	two ways wireless transmitter power the winch

Unpacking

Winch assembly	1 pc
Control box	1 pc
Remote control	1 pc
Synthetic rope with BossHook M	1 pc
• Hawse fairlead	1 pc
• 1.8 m (6′) 2 gauge battery lead	1 pc
• Wireless transmitter	1 pc


Read this manual carefully

You should carefully read and understand this manual before operating it. Careless winch operation may result in personal injury hazards or property damage.

Installation

Before using the winch, make sure all electrical components have no corrosion or damaged; the environment should be clear and dry.


- Winch and hawse fairlead mountings
 - It is very important that the winch will be mounted on a flat and hard surface of mounting channel in order to make sure the motor, drum and gearbox housing are aligned correctly.




- · Hawse fairlead does not mount to the winch directly.
- The synthetic rope shall be wound in an under-wound orientation only.
- Four (4) M10 x 1.50 pitch 10.9 grade with 63.8 N-m torque settings (maximum) high tensile steel bolts must be used in order to sustain the loads imposed on the winch mounting.
- Two (2) M10 x 1.50 pitch stainless steel bolts must be used for fastening the hawse fairlead into the mounting channel.

Wiring Diagram

• Attach the ground lead firmly to the negative (–) battery terminal and power lead to the positive (+) battery terminal. The voltage drop for the winch motor must not exceed 10% of the nominal voltage of 12V DC.



- ▶ Nut fastening for motor & contactor
 - 1. Holding the lower nut on the stub and fastening the upper nut clockwise.
 - 2. The torque setting for nut is 14 N-m/124 lb-in.



Warning


• The winch is not intended to be used in any manner for the movement or lifting of personnel.

- The rated line pull shown is based on the first layer of rope on the drum.
- The rope winding on the drum shall remain 10 wraps from the drum to support the rated load.
- Manufacturer is not responsible for the results of misuse, misapplication, faulty installation or abuse of synthetic rope in any way.

Parts List

Item No.	Description	Part No.	Qty
1	Waterproof motor w/housing 12V	883882	1
2	Tie bar kit	884517	2
3	Motor coupling	880005	1
4	Drum bushing	880006	2
5	Drum kit	881521	1
6	Gearbox support rack	883906	1
7	Grounding lead	880009	1
8	Synthetic rope	884513	1
9	1 st shaft	881523	1
10	3 rd ring gear kit	883900	1
11	3 rd stage carrier	881960	1
12	2 nd stage carrier	881961	1
13	1 st stage carrier	881962	1
14	1 st & 2 nd ring gear	881963	1
15	1 st pinion	881964	1
16	Clutch kit	883885	1
17	Gear box kit	883901	1
18	Cone brake disc kit	880122	1
19	Brake cover kit	883886	1
20	Hawse fairlead	883410	1
21	Mounting hardware	884311	1
22	Remote control	883887	1
23	Handsaver strap	880026	1
24	Bridge Control box 12V	884392	1
24-1	Control pack 12V	883889	1
24-2	Remote socket kit 12V	883890	1
24-3	PC board kit	883891	1
24-4	On/Off switch kit	884091	1
24-5	Power lead	883893	1
24-6	Motor thermal connector	883894	1
24-7	Wireless transmitter	883822	1
24-8	High Current Fuses kit	884105	1
25	Brake clutch base	881100	1
26	BossHook M	884343	1

Winch Assembly



2024/11/08 Ver:01